

The Gallery System

DIRECTIONS

HOOKS

Gallery Push Button Hook

The Gallery Push-Button Hooks are for use with Gallery Stainless Steel Cable Hangers or the Traditional Picture Rail System.

DIRECTIONS: Feed the stainless steel cable into the hole in the top of the hook. Push the button down and the hook will move freely on the cable. The hook grips the cable when the button is released.

RECOMMENDED WEIGHT: On the Gallery Stainless Steel Cable Hangers - 20kg per hook.

ADHESIVE FOAM PADS: 20 of these are supplied in each pack of hooks. Stick one of these pads near the lower corners at the back of each frame. They help stabilize the frames and keep them straight.

