




DIRECTIONS

Slimline Push Button Hook & Clearline Push Button Hook (black)

Slimline Push Button hooks are suitable for the Slimline Stainless Steel Cable hangers and the Clearline Push Button hooks (black) are suitable for use with the Slimline Clearline (also for use with The Gallery System Clearline hangers). Both hooks function in the same manner.

Directions:

Thread the end of the hanger into the top of the hook. To move the hook along the hanger press the button on the top of the hook as shown. While the button is down the hook will move freely. The hook grips the cable when the button is released.



Recommended Weights:

See the [Slimline Weight Guide on page 5](#) for maximum weight specifications and compatibility of hangers and hooks.